

SPIRE Fourier Transform Spectrometer Observing Modes

Edward Polehampton


Rutherford Appleton Laboratory, UK University of Lethbridge, Canada

SPIRE FTS Observing Modes

Edward Polehampton

The SPIRE Imaging FTS


- Fourier Transform Spectrometer → entire spectral coverage is observed in one go
- 2 Bolometer detector arrays for short and long wavelength bands



Herschel Open Time Workshop



Spectral Coverage





Observing Choices

Source size

Single point (1 FOV with diameter of 2')

Raster (many FOVs)

Spatial sampling

Sparse 2 beam spacing

Intermediate 1 beam spacing

Full ½ beam spacing (Nyquist) Spectral resolution

(unapodised)

High 0.04 cm⁻¹ (1.2 GHz)

Medium 0.25 cm⁻¹ (7.5 GHz)


Low 1.0 cm⁻¹ (30 GHz)

(constant in frequency)




Point Source Spectrum

- \rightarrow single point: sparse
- Always get data from whole array
- HSpot shows location of array pixels for sparse mode



Point Source Spectrum 2


Instrumental profile is a Sinc function



with a FWHM 1.2 x resolution

 $FWHM = 0.048 \text{ cm}^{-1} = 1.4 \text{ GHz}$

Apodisation reduces ringing in the side lobes






Point Source Spectrum 3

LOW $\Delta \sigma = 1.0 \text{ cm}^{-1} (30 \text{ GHz});$ R = 52 - 15

- Continuum measurements
- 36 resolution elements across the whole range (sampled at ¹/₄ res. element)





HIGH

Point Source Spectrum 4

INTERMEDIATE $\Delta \sigma = 0.25 \text{ cm}^{-1} (7.5 \text{ GHz}); R=200 - 60$

Δσ = 0.04 cm⁻¹ (1.2 GHz); *R***=1290 – 370**


- Line spectroscopy
- Measurement of total integrated line fluxes (line widths 280 – 840 km/s in HIGH resolution mode)

HIGH + LOW

• Line spectroscopy with high S/N continuum measurement (number of HIGH and LOW resolution scans are set independently)




Spectral resolution in HIGH & INTERMEDIATE modes





Extended Source

 \rightarrow SINGLE POINT: SPARSE, INTERMEDIATE or FULL



SPIRE FTS Observing Modes



Extended Source 2: Raster Map

 \rightarrow RASTER: SPARSE, INTERMEDIATE or FULL


- Raster map is made up from a combination of individual fields of view
- Raster direction is fixed to spacecraft axes not to sky coordinates → check visualisation!
- Coverage is a parallelogram on sky
- Split into separate observations to make more complicated shapes



Y

height

- Herschel Open Time Workshop Z
- Raster is performed in spacecraft coordinates
- Therefore orientation on the sky changes depending on source position & visibility constraints






Herschel Open Time Workshop

ESTEC

Raster starts here



- Raster is performed in spacecraft coordinates
- Therefore orientation on the sky changes depending on source position & visibility constraints

SPIRE FTS Observing Modes

Y



Sensitivity

- Mechanism makes scans in pairs (forward & reverse)
- Integration time depends on repeats of scan pairs (at least 2 repeats so glitches can be removed)
- Average point source sensitivity (Low Res):
 ~1.2 Jy (1σ in 1 sec) ~100 mJy 5σ in 1 hour

For variation of sensitivity with wavelength, see the SPIRE Observer's Manual **Note that all sensitivities are quoted for a point source on axis**

Minimum times for each spectral resolution are:

LOW (30 GHz)	26 sec \rightarrow	0.24 Jy RMS
MEDIUM (7.5 GHz)	98 sec \rightarrow	$0.5 \text{ Jy RMS} \rightarrow 3.6 \times 10^{-17} \text{ W/m}^2$
HIGH (1.2 GHz)	269 sec $ ightarrow$	1.8 Jy RMS \rightarrow 2.2 x 10⁻¹⁷ W/m²



Why use SPIRE for line spectroscopy?

- In HIGH resolution mode (min length 269 sec), RMS in line flux is 2.2 x 10⁻¹⁷ W/m²
- What does this integrated flux mean in terms of temperature units?
 - Depends on intrinsic line width

				CONCLUSION
Wavelength	535 µm	200 µm		SPIRE is useful for
Frequency	560 GHz	1499 GHz		<i>integrated flux</i> measurements of <i>BROAD lines</i> , particularly at high frequencies
T _{rms} (20 km/s line)	0.13 K	0.03 K		
T _{rms} (5 km/s line)	0.51 K	0.14 K		
	•		•	

intrinsic line width


Aditional advantages:

- always observes full spectral range simultaneously
- always get a sparse map of the source

Edward Polehampton



HSpot





More Details

Refer to the AO for more details, including HSpot examples:

http://herschel.esac.esa.int/Docs/SPIRE/html/spire_om.html

Specifically:

- **Chapter 2,** Section 2.3 (*"Spectrometer"*)
- **Chapter 3**, Section 3.1 ("Sensitivity")
- **Chapter 4,** Section 4.2 (*"Spectrometer AOT Modes"*)
- Chapter 6, Section 6.4

("HSpot Components for Setting up a SPIRE Spectrometer Observation")